

WARRANTIES

CONTRIVE GUARANTEES FOR TWO YEARS FROM THE DATE OF MANUFACTURE OF ITS PRODUCT TO REPLACE, OR, AT ITS OPTION, TO REPAIR ANY PRODUCT OR PART THEREOF WHICH IS FOUND DEFECTIVE IN MATERIAL OR WORKMANSHIP OR WHICH OTHERWISE FAILS TO CONFORM TO THE DESCRIPTION OF ITS SALES ORDER.

CONTRIVE MAKES NO WARRANTY OF MERCHANTABILITY OR ANY OTHER WARRANTY EXPRESS OR IMPLIED. IN NO EVENT SHALL CONTRIVE BE LIABLE FOR CONSEQUENTIAL OR SPECIAL DAMAGES OF ANY NATURE WHICH MAY ARISE IN CONNECTION WITH SUCH PRODUCTS.

THE WARRANTY DOES NOT APPLY IN CASE OF IMPROPER USE

© COPYRIGHT 2017 CONTRIVE SRL ITALY.
SOME RIGHTS RESERVED.

INFORMATION CONTAINED IN THIS DOCUMENT ARE SUBJECT TO CHANGE WITHOUT NOTICE. PRODUCT NAMES, CORPORATE NAMES OR TITLES USED WITHIN THIS DOCUMENT MAY BE TRADEMARKS OR REGISTERED TRADEMARKS OF OTHER COMPANIES AND ARE MENTIONED ONLY IN AN EXPLANATORY MANNER TO THE READERS' BENEFIT, AND WITHOUT INTENTION TO INFRINGE.

WHILE EVERY EFFORT HAS BEEN MADE TO MAKE SURE THE INFORMATION IN THIS DOCUMENT IS CORRECT, CONTRIVE CAN NOT BE LIABLE FOR ANY DAMAGES

Port

Porta
Port
Puerto
Porta
Anschluss

USB A male

Current in transmission

Corrente in trasmissione
Courant en transmission
Corriente en transmisión
Corrente na transmissão
Übertragungsverbrauch

<70 mA

Quiescent current

Corrente a riposo
Courant de repos
Corriente de reposo
Corrente quieta
Ruhestrom

<20 mA

Weight


Peso
Poids
Peso
Peso
Gewicht

20 g

Dimensions

Dimensioni
Dimensions
Dimensiones
Dimensões

71 × 23 × 8,7



B1480.01 / 0220

www.burner-control.com



Q|beam.USB

Q-SERIES

INFRARED ADAPTER
ADATTATORE INFRAROSSO
ADAPTATEUR INFRAROUGE
INFRAROT-ADAPTER
ADAPTADOR INFRARROJO
ADAPTADOR INFRATERMELHO

This USB adapter can be used together with:

- Android Smartphones and Tablets equipped with USB-OTG by means of Q|beam APP
 - Computers equipped with USB port by means of Q|tool software
- <https://www.burner-control.com/E/QBEAM.php>

PROCEDURE

- 1 Press the button to put device in MANUAL SHUTDOWN.
- 2 Point and keep Q|beam.USB toward the device push button at a distance of 30 to 60 cm.

Questo adattatore USB può essere utilizzato con:

- Smartphone e tablet Android con USB-OTG tramite APP Q|beam
 - Computer dotati di porta USB tramite software Q|tool
- <https://www.burner-control.com/E/QBEAM.php>

PROCEDURA

- 1 Premere il pulsante frontale per forzare il dispositivo in ARRESTO MANUALE.
- 2 Puntare e mantenere Q | beam.USB verso il pulsante del Dispositivo ad una distanza da 30 a 60 cm.

Cet adaptateur USB peut être utilisé avec::

- Smartphones et tablettes Android équipés d'USB-OTG au moyen de l'application Q|beam
 - Ordinateurs équipés d'un port USB au moyen du logiciel Q|tool
- <https://www.burner-control.com/E/QBEAM.php>

PROCÉDURE

- 1 Appuyez le bouton pour mettre l'appareil en ARRET MANUEL.
- 2 Pointez et maintenez Q | beam.USB vers le bouton-poussoir de l'appareil à une distance de 30 à 60 cm.

Este adaptador USB se puede usar junto con::

- Smartphones y Tablets con Android equipados con USB-OTG mediante la aplicación Q|beam
 - Ordenadores con puerto USB mediante el software Q|tool
- <https://www.burner-control.com/E/QBEAM.php>

PROCEDIMENTO

- 1 Presione la tecla para poner el dispositivo en PARADA MANUAL.
- 2 Apunte y mantenga Q | beam.USB hacia el botón del dispositivo A una distancia de 30 a 60 cm.

Este adaptador USB pode ser usado junto com:

- Smartphones e tablets Android equipados com USB-OTG por meio do aplicativo Q|beam
 - Computadores com porta USB por meio ou software Q|tool
- <https://www.burner-control.com/E/QBEAM.php>

PROCEDIMENTO

- 1 Pressione o botão para colocar o dispositivo em DESLIGAMENTO MANUAL.
- 2 Aponte e mantenha o Q|beam.USB em direção ao botão do dispositivo a uma distância de 30 a 60 cm.

Dieser USB-Adapter kann zusammen verwendet werden mit:

- Android-Smartphones und -Tablets mit USB-OTG mittels Q|beam-APP
 - Computer mit USB-Anschluss mittels Q|tool-Software
- <https://www.burner-control.com/E/QBEAM.php>

VERFAHREN

- 1 Drücken Sie die Taste, um das Gerät in MANUELLE ABSCHALTUNG zu stellen.
- 2 Richten Sie Q | Beam.USB in einem Abstand von 30 bis 60 cm auf den Gerätetaster.